

Part Number	<input type="text" value="D350-636-049"/>	Box Part Number	<input type="text"/>	Dimension	<input type="text"/>
Description	<input type="text" value="Wearshoe Installation"/>	Other Packaging	<input type="text"/>		<input type="text"/>
		Logo Decals	<input type="text"/>	<input type="text"/>	

Packaging Instructions and Decal Placement

D350-636-049

Take telescopic tube and add foam to each end. Take wearplate, hardware and paperwork and tape together. Insert inside the tube. Close tube and tape with clear tape so it will not open. Apply label D2729-3 as per instructions in QSI 014.

D2729-4

N/A

D2729-3

 <p>DART AEROSPACE</p>	Dart Aerospace Ltd. 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
WEARSHOE INSTALLATION	
P/N: D350-636-049	CHG001
S/N: SXXXXXX	

Revision: Draft
Date: 18.10.23

DAS
16
9-89

18/10/24